Dreamland

RELAXWELL HEATED CUSHION

TYPE E0806

Operating instructions

ILLUSTRATIVE GUIDE

[A] **RELAXWELL HEATED CUSHION**



Remove Heatpad from cushion to connect the control to the connector

[B]



1 - LED Display
2 - Stand by light
3 - Temperature selector
4 - Power On/Off switch



Connecting the heatpad

TECHNICAL DATA

Dreamland

TYPE E0806 220-240 V 50 Hz 15 W (max. 110 W)

HEATED CUSHION INSTRUCTIONS FOR USE

Dear customer, DREAMLAND thanks you for purchasing this product. We are certain you will appreciate the quality and reliability of this heatpad, designed and manufactured with customer satisfaction in mind. These instructions for use have been drawn up in accordance with European standard EN 62079.

IMPORTANT INSTRUCTIONS KEEP FOR FUTURE USE

ATTENTION!
Instructions and warnings for a safe use.

Please read the operating instructions and safety warnings in particular before using the appliance and follow these at all times. Keep this manual and illustrative guide with the appliance for future consultation. Should you pass the appliance on to another user, make sure to also include this documentation. Should certain parts of this user manual be difficult to understand or should doubts arise, contact the company before using the product, at the address indicated on the last page.

CONTENTS

SAFETY WARNINGS	page	1
SYMBOLS	page	3
DESCRIPTION OF THE HEATED CUSHION CONTROL	page	3
USING THE HEATPAD	page	3
USE	page	3
CLEANING AND MAINTENANCE	page	4
DISPOSAL	page	4
ASSISTANCE AND WARRANTY	page	5
ILLUSTRATIVE GUIDE	page	I
TECHNICAL DATA	page	II

SAFETY WARNINGS

- **After having removed the heated cushion from its packaging, check for any damage caused during transport. If damaged, do not use the heatpad and contact the authorised service centre.**
- **Do not let children play with the packaging! Keep the plastic wrapping out of the reach of children; risk of suffocation!**
- **Before connecting the heated cushion, check that the mains voltage data reported on the label corresponds to that of the available electric mains. The label is attached to the heatpad.**

GB

- **This heated cushion is intended exclusively as a heatpad for home use. Any other use is improper and potentially dangerous.**
- **The heatpad is not to be used by persons (including children) with reduced physical, sensorial or mental abilities, or with no experience or knowledge, unless supervised by a person responsible for their safety, supervision or after having received instructions regarding its use.**
- **Children must be supervised to ensure they do not play with the heatpad.**
- **Do not use the heatpad for ill people, for infants or for persons who are insensitive to heat.**
- **This heated cushion must not be used by children if the control devices have not been set beforehand by a parent or guardian or if the child has not been properly instructed on how to use the device safely.**
- **WARNING – NOT suitable for children under the age of 3. Children under the age of 3 must not use the heatpad as they are unable to react in the event of overheating.**
- **DO NOT activate the temperature control with wet hands.**
- **DO NOT pull the power cord or the heatpad itself to remove the plug from the socket.**
- **Always disconnect the heatpad from the mains before cleaning or performing maintenance and when the heatpad is not in use.**
- **In case of a fault or malfunctioning of the heatpad, switch it off and do not tamper with it. If the heated cushion needs to be repaired, contact an authorised technical service centre.**
- **If the power cord is damaged, it must be replaced by an authorised technical service centre, so as to prevent all risks.**
- **The heatpad must be used solely with the types of control indicated on the label.**
- **Inspect the heated cushion frequently to check for signs of wear and tear. If such signs are found or if the heated cushion has been used incorrectly, contact an authorised technical assistance centre before continuing to use it.**

ATTENTION ! It is recommended that people with pacemakers do not use the heatpad. Please check with your cardiologist.

- **This heated cushion is not intended for medical use inside of hospitals.**

- **DO NOT use the heatpad if it is wet.**
- **DO NOT use the heatpad to keep animals warm.**
- **DO NOT leave the heatpad running while you sleep.**
- **DO NOT INSERT PINS OR NEEDLES.**
- **Application of the heatpad for a long time at high temperature can burn the skin.**

SYMBOLS

	Protection class II.		Prohibited actions.
	Warning.		Temperature selector (3).
	Power ON/OFF (4).		STAND-BY light (2).

DESCRIPTION OF THE HEATPAD CONTROL

1 - Temperature display.
2 - Stand-by Display.
3 - Temperature selector.
4 - Power ON/OFF.
5 - Heatpad connector
6 - Control connector

USING THE HEATED CUSHION

The heated cushion is designed to warm the body.
The heatpad can be placed on parts of the body, such as: neck, shoulders, back, abdomen and joints, depending on the relative model.

USE

CONNECTING AND REMOVING THE INTELLIHEAT CONTROL

ATTENTION! The heatpad can only be used with the control supplied. The relative model is specified on the label sewn on the heatpad.

- Insert the control connector (6) to the heatpad connector (5), to connect the intelliheat control to the connector on the heatpad.
- Insert the plug in the socket.

SWITCHING THE HEATPAD ON AND SELECTING THE TEMPERATURE

- Press down on the ON/OFF switch (4) to turn the heated cushion on.
- The display (1) will light up and the temperature will be automatically set to position 5 which is fast heat.
- Select the desired temperature (from 1 = low, 5 = high. For fast heat up select 5) by pressing the temperature button (3) until your chosen temperature lights up on the display (1).

AUTOMATIC SHUTDOWN

- The heated cushion will provide a 3 hour heat treatment, then it will automatically shut

off. The standby light (2), will be blue, after the 3 hours of operating to indicate that the product has switched off automatically.
- Switch the heatpad back on by pressing the On/Off switch twice, and select your preferred temperature setting. 1 = low heat, 5 = High heat.

SWITCH-OFF

- Switch the heatpad off by pressing the ON/OFF switch (4).
- Remove the plug from the socket.

CLEANING AND MAINTENANCE

The heated cushion + cover are washable. The washing symbols are also on the heatpad care label.

Wash at 30°C.	Do not bleach.	Do not dry-clean.
Tumble-dry at less than 40°C.	Do not iron.	Wash at 40°C. (Cushion+Cover only)

WASHING INSTRUCTIONS

Always disconnect the heatpad before washing.

MACHINE WASHING

- The fur cover and the cushion can be machine washed at 40°C with a normal cycle.
- The heatpad can be machine washed at 30°C with a normal cycle.
- Only the gentle spin cycle is to be used. DO NOT set an additional spin cycle.

DRYING

- Set the dryer at a low temperature.
- Do not apply pegs on the electrical parts when hanging the heatpad to dry in order not to damage them.
- DO NOT use the heatpad until it is completely dry.

DISPOSAL

The product is packaged in recyclable materials. Dispose of it in compliance with the environmental protection standards.

The product must be disposed of appropriately, in compliance with European standard 2002/96/EC. The recyclable materials contained in the appliance must be recovered so as to prevent environmental pollution. For further information, contact the local disposal body or the appliance dealer.

ASSISTANCE AND WARRANTY

GUARANTEE

1. The appliance is guaranteed for a period of two years from purchase. Your receipt / invoice is your proof of purchase.
2. The appliance is guaranteed against any defects arising from manufacture during this period. Should this be evident we will repair or replace it.
3. The guarantee does not apply to instances of customer misuse/abuse.
4. The guarantee does not apply in professional / commercial usage situations.
5. The guarantee does not affect your statutory rights.

SERVICING

For repair / replacement under the terms of our guarantee, the appliance must be returned to the Service Centre accompanied by a valid proof of purchase.

CUSTOMER SERVICE

PO BOX 166 Middlewich-CHESHIRE-CW10 0ZU - Tel:01606 837222
e-mail: info@imetec.co.uk - www.dreamlanduk.co.uk

Dreamland

MI001253
0613 (MMYY)